



### Removing the OLD Ballast

- 1) Drill out the rivets in the top cover
- 2) Drill out the rivets holding the PCB
- 3) Cut the wires – remove the PCB

### Fitting the illuminous F15T8 LED tube [Model Number: EV-LED-T8-18](#) :

- 1) You Only need 1 wire to each Socket at each end of the Tube. Some Fixtures have 2 Wires, some have 1 wire to each socket. Pick One.
- 2) Each tube has 2 pins each end, you ONLY need to connect to ONE of the pins on each end, pick either one ! One end is Positive, the other end is GND / Negative
- 3) Change the wiring to look like this:



- a) Wire One End to Positive (just one Wire from each End Socket)
- b) Wire the other end to Negative (just one wire from each Socket)